



### INSTALLATION OF A SKYLIGHT SHEET

(Refer to your Absco shed Instruction manual "ROOF PANEL ASSEMBLY" section for further details)

The addition of a skylight in any Absco garden shed will alter the sequence of existing pre-punched holes in the roof panel. Carefully drill 3mm holes to accommodate the screws. Some extra 3mm holes may have to be drilled in positions marked above when securing the roof panel to the wall panel.

### CAUTION

1. Take care not to damage the skylight sheet during the above process. Drill holes slowly to avoid enlarging the hole size.
2. Do not over-tighten screws as cracking of the fibreglass may occur.
3. Ordinary household scissors can be used to cut the skylight to a shorter length if needed.
4. The skylight sheet must not be positioned closer than 450mm from the end wall of any garden shed.
5. The skylight sheet must not be positioned closer than 450mm from the portal frame in the larger workshop or utility models.



Download the Absco  
Sheds Assembly App  
for instructional videos

