


1.52mW x 1.52mD x 1.95mH

AU: 1800 029 701 NZ: 0800 466 444

admin@absco.com.au www.abscosheds.com.au



For construction in non-cyclonic areas

Wind rating: N2 as per AS4055-2021.

If you require a higher wind rating please contact

us: admin@absco.com.au or 1800 029 701

NOTE: This shed can be upgraded to wind rating: C1 as per AS4055-2021 with the additional purchase of a Cyclone Kit.



**DOWNLOAD OUR APP FOR ASSEMBLY** 



Model: 15151GK

When laying concrete slab, ensure there is a rebated edge 25mm deep around the perimeter. This will help water egress from the base of the shed.

### **PLEASE LEAVE A REVIEW**

Tell us about your experience! Visit www.abscosheds.com.au/review



1.52mW x 1.52mD x 1.95mH

### **GENERAL INSTRUCTIONS**

- Before commencing any assembly, read through these instructions in detail to gain a thorough understanding of assembly methods and associated details.
- Unpack the carton and carefully identify and check off all the parts against the parts described and illustrated on "COMPONENTS PACKING LIST" pages.
- Some drilling is required during assembly; Carefully clean away steel shavings (swarf) as you go. Use a soft brush or vacuum as you go to prevent damage to your shed.

### SITE PREPARATION

- The site for the shed must be level. An uneven surface may result in misalignment of parts.
- The shed shall be erected on top of a reinforced concrete slab and anchored down appropriately illustrated on "FINAL CONSTRUCTION" page.

### **TOOLS REQUIRED**



### **SAFETY NOTES**

- Some parts may have sharp edges. It is advisable to wear gloves when handling these items and safety glasses if drilling holes. Sensible shoes are highly recommended.
- Do not erect your shed in windy conditions.
- Ensure that the shed is securely anchored to a solid foundation immediately after construction is completed.
- It is highly recommended to erect the shed with two or more people.
- Do not sit, stand or walk on the roof of your shed.

## **RECOMMENDED**











1.4

Assembly Instruction Manual Model: 15151GK



1.52mW x 1.52mD x 1.95mH

## **COMPONENT PACKING LIST**

Check off all components.

QTY	COMPONENT DESCRIPTION	PART NO.	СНК	QTY	COMPONENT DESCRIPTION	PART NO.	СНК
2	STEEL SHEET 1785mm X 773mm	30A		1	STEEL SHEET 1850mm TO MIDPOINT X 773mm	29R	
2	STEEL SHEET 1852mm TO MIDPOINT X 773mm	36L		1	STEEL SHEET 1852mm TO MIDPOINT X 773mm	36R	
4	STEEL SHEET 795mm X 773mm	52A		1	STEEL SHEET 1785mm X 711mm	34A	
1	STEEL SHEET 1725mm X 773mm	В		2	PEAK BRACE	15A	
1	RIDGE BEAM L = 1513mm	97C					



1.52mW x 1.52mD x 1.95mH

## **COMPONENT PACKING LIST**

Check off all components.

QTY	COMPONENT DESCRIPTION	PART NO.	СНК	QTY	COMPONENT DESCRIPTION	PART NO.	СНК	
4	CHANNEL L = 1513mm	81E		1	CHANNEL WITH HINGES L = 1725mm	58A		
1	CHANNEL L = 1725mm	58B		2	CHANNEL L = 773mm	58C		
2	CHANNEL L = 1513mm	60C		1	CHANNEL L = 781mm	79C		
2	CHANNEL L = 767mm	82R		2	CHANNEL L = 767mm	82L		
NOTCHED CHANNEL								
1	CHANNEL L = 1785mm	80A		1	CHANNEL L = 1513mm	53A		
1	CHANNEL L = 1513mm	53B		1	CHANNEL L = 1513mm	53C		
1	CHANNEL L = 1513mm	81F						



1.52mW x 1.52mD x 1.95mH

## **COMPONENT PACKING LIST**

Check off all components.

QTY	COMPONENT DESCRIPTION	PART NO.	СНК	QTY	COMPONENT DESCRIPTION	PART NO.		
1	JAMB L = 1785mm	89A		1	JAMB L = 783mm	90C		
1	JAMB L = 1785mm	89B		4	LIP TRIM L = 795mm	85A		
2	JAMB L = 1120mm	91A						
INSTRUCTION & FITTINGS PACK								
1	DOOR STRAP L = 165mm	12A		6	SELF TAPPING SCREWS L = 20mm	FAST 013		
2	CAP GABLE $L = 170$ mm	14A		1	SELF TAPPING SCREWS PACK 100	FAST 001		
1	ASSEMBLY INSTRUCTION MANUAL			1	PSTKSGL SINGLE DOOR FITTINGS PACK			
	PSTKSGL - SINGLE DOOR FITTINGS PACK							
1	DOOR PADBOLT	FAST 006		1	PADBOLT HASP	FAST 007		
1	3mm DRILL BIT	DRILL		1	PHILLIPS DRIVER BIT	FAST 038		
1	8G x 10 mm SELF TAPPING SCREW PACK 220	FAST 001		6	3.2x8mm POP RIVETS	FAST 009		
6	3/16" COUNTER SUNK SCREWS	FAST 004		6	3/16" COUNTER SUNK NUTS	FAST 005		




1.52mW x 1.52mD x 1.95mH

### **SNAPTITE ASSEMBLY GUIDE**

The Snaptite Assembly System locks end channels to all roof and wall sheets without the need for tools and fasteners.

To assemble each panel, the perimeter channels are secured to the top and bottom of each panel. Gently tap the channel over the SNAPTITE lugs on the sheet, working along the sheet.

Each perimeter channel must finish flush with the edges of the sheets. Simply tap the channel along the sheets until each end is neatly flush. If you need to remove channels from the panels, slide it off from the side.





Channel locks the shed panel into position without the need for screws!

### **FASTENING SYMBOLS**




Secure channel to sheeting by SNAPTiTE fastening method.




Join components together with one screw at this location only, as some channels have extra holes that are not required for this model of shed.



Do not join components together at this location yet, as the screws may obstruct further assembly of the other components.





Model: 15151GK

4mm nut and bolt set.

Absco Industries Asser


Assembly Instruction Manual

05/02/2025



1.52mW x 1.52mD x 1.95mH

## **OVERVIEW OF ROOF COMPONENTS**




**Absco Industries** Assembly Instruction Manual Model: 15151GK 05/02/2025 1.4



1.52mW x 1.52mD x 1.95mH

## **OVERVIEW OF WALL COMPONENTS**






1.52mW x 1.52mD x 1.95mH

## **REAR PANEL ASSEMBLY**


1x required.





1.52mW x 1.52mD x 1.95mH


## **ROOF PANEL ASSEMBLY**





1.52mW x 1.52mD x 1.95mH

## **RIGHT SIDE PANEL ASSEMBLY**








05/02/2025



1.52mW x 1.52mD x 1.95mH




1.4

12



1.52mW x 1.52mD x 1.95mH







1.52mW x 1.52mD x 1.95mH

## **DOOR PANEL ASSEMBLY** SINGLE DOOR

1x required.



Vertical door channels are installed in the opposite orientation compared to the horizontal door channels.




1.4


14



1.52mW x 1.52mD x 1.95mH




NOTE: The holes to fasten the padbolt hasp are not pre-punched to allow for proper alignment. Position the hasp centrally over the padbolt shaft and drill 3mm holes and secure with screws.





1.52mW x 1.52mD x 1.95mH


### PANEL CONSTRUCTION






1.52mW x 1.52mD x 1.95mH







1.52mW x 1.52mD x 1.95mH





1.52mW x 1.52mD x 1.95mH

### **Absco Gable Roof Shed Notes**

### General


- 1.G This instruction manual shall be read in conjunction with other consultants drawings, specifications and written instructions provided by Absco and/or their representatives.
- 2.G The drawings provided herein are for installation and structural engineering purposes only. If discrepancies are discovered within the documentation provided, these shall be brought to the attention of Absco and written approvals obtained prior to commencing the affected section of work.
- 3.G If in doubt ask.
- 4.G Until approvals from the local authorities are obtained, commencement of construction from these drawings shall not commence.
- 5.G Unless varied by the project specification, all materials and workmanship shall be undertaken in accordance with the relevant Australian standards and the by-laws and ordinances of the relevant building authorities.
- 6.G All dimensions indicated in these drawings shall be verified on site by the installation contractor. Scaling of drawings shall not be undertaken.
- 7.G Prior to commencing works on site, the contractor shall verify the position of all services in the area to ensure that the construction does not interfere with any of those services.
- 8.G During installation on site the shed structures shall be maintained in a stable condition with no part becoming overstressed or permanently deformed.
- 9.G In circumstances where the shed has been installed in a manner which is inconsistent with the installation manual, structural certification shall be void.
- 10.G The structural components detailed within this installation manual have been designed for the following loads in accordance with AS/NZS1170 based on a Class 10a, Type 2 structure:
- Roof Live Load: 0.25 kPa uniformly distributed or 1.1 kN concentrated as per AS/NZS1170.1 and is only valid when the doors of the shed are shut.
- Wind Load: Classification N2, Non-Cyclonic to AS4055 where Vu = 40 m/s, Vs = 26 m/s

Windward wall Cpe = 0.7

Leeward Wall Cp, e = -0.3 to -0.5 as applicable based on shed geometry


Side Wall Cp, e = -0.5 to -0.65 as applicable based on shed geometry

Roof Cp, e = -0.5 to -1.3 depending on wind direction



AU: 1800 029 701 NZ: 0800 466 444

Model: 15151GK



1.4

19



1.52mW x 1.52mD x 1.95mH


### **Absco Gable Roof Shed Notes**

### Steelwork

- 1.S All structural steelwork shall have a corrosion protection system applied consistent with AS/NZS 2312-2002.
- 2.S All structural steelwork detailed within this installation manual shall be minimum Grade 550 for roll formed sections (including roof and wall sheeting) and Grade 250 for angle sections.
- 3.S All roof, and wall sheeting shall be minimum base metal thickness of 0.3mm
- 4.S All snaptite channels and jambs shall be minimum base metal thickness of 0.42mm
- 5.S All top hats shall be minimum base metal thickness of 1.0mm
- 6.S All screw fasteners shall be Phil Pan Head Zinc Plated #8 x 3/4" (STP0820)
- 7.S All bolt fasteners for anchoring shall be M10 minimum grade 4.6/S
- 8.S Installation of screw fasteners shall generally be undertaken in accordance with the relevant provisions of AS1562.

## **Supporting Slab and Foundations**

- 1.F The supporting slab foundation for the garden shed shall be of a minimum size indicated on the installation manual. The top surface of the formed slab shall be level and free of any irregularities which would inhibit the installation of the shed.
- 2.F The structural engineering design for the supporting slab foundation shall be undertaken by a suitably qualified structural engineer. The design shall consider all relevent provision of AS3600 and AS2870.
- 3.F Between adjacent footings or excavations, the contractor installing the slab foundation shall not exceed a rise of 1 in a run of 2 in line of slope.
- 4.F Unless approved in writing by the slab foundation engineer, the limits of excavations near existing footings shall be in accordance with that indicated below.



The contactor shall undertake investigatory localised excavations near existing footings to ascertain their depth prior to excavating adjacent to them. It is noted that excavating to a depth below that indicated above shall not be undertaken without the written approval from the engineer.

Absco Industries Assembly Instruction Manual Model: 15151GK 05/02/2025 1.4 20



1.52mW x 1.52mD x 1.95mH

## **Absco Sheds Storage Guidelines**

- Absco Sheds are designed to be weatherproof for normal weather conditions. In the event of extreme weather conditions such as heavy rain, combined with high wind gusts, the ridge capping, sheeting joins, screw fixings etc., may exhibit minor deformations which may allow some water entry. These areas should be checked regularly to ensure that maximum strength and protection is maintained.
- Other weather conditions such as extreme heat and extreme cold, moist or dry air can influence the effects of concrete floor moisture and/or condensation on the underside of the roof sheets.
- Absco Sheds and storage units are primarily used for storage of garden equipment such as lawnmowers, wheelbarrows, garden tools etc. Storage items that might be adversely affected by any of the above conditions may require additional protection such as being sealed or covered by plastic sheets and/or stacked above the concrete floor on timber slats.
- Waterproof sealants may be used to offer further protection where required around joins and screw fixings, as can rubber door seals and other products which are available from most hardware outlets.
- Placement of waterproof sealants (silicone) between the base of the shed and concrete slab is not recommended, as this process can have a reverse effect, preventing excess water from escaping, resulting with water accumulating and being trapped inside the shed.
- Absco accepts no responsibility for water entry, floor moisture, condensation or the condition of the Contents inside your Absco steel building arising from any of the pre-mentioned weather conditions.
- Absco accepts no responsibility for structural damage if doors were left open and/or not secured during a weather event.

### **Post-Installation Care**

Clear final product of steel fillings (swarf) caused by drilling holes and tek screws.


Failure to do so may cause discolouration of surfaces and promote corrosion.

Refer to warranty for more details



AU: 1800 029 701 NZ: 0800 466 444

Model: 15151GK



1.4

21

#### 4. WARRANTY LIMITATIONS / EXCLUSIONS

- 4.1. To the extent permitted by law, this warranty will not apply where:
- (a) the Product has been installed or used for a purpose that is not an Authorised Purpose;
- (b) the Product has not been installed, assembled, maintained and/or operated in complete compliance with ABSCO's Product Guide;
- (c) the Product has been used to store corrosive materials such as fertiliser or chlorine:
- (d) the Product was installed in excess of 12 months after the purchase of the Product;
- (e) the Product has not been installed in accordance with the relevant standards, codes and statutory regulations;
- (f) the Defect is determined to have been caused by storm, wind, rain, earthquake. fire, snow or poor foundations:
- (g) the Defect is, or is the result of, surface deterioration of panels caused by 'swarf' (tiny particles of steel debris left from cutting, grinding or drilling operations):
- (h) the Product has been installed in an Excluded Environment;
- (i) the Product has been subject to accident, negligence, alteration, abuse or misuse:
- (j) the Defect is determined to be the result of overloading; or
- (k) ABSCO determines that the Defect is the result of a failure of a thirdparty product.
- 4.2. You acknowledge that:
- (a) dimensions and colour of the Product are subject to normal manufacturing variations and tolerances, and that reasonable variances are not considered a Defect under this warranty; and
- (b) this warranty is limited to the repair or replacement of Defects in the Product and does not extend to any other product or any other consequential or indirect damage incurred as a result of the Defect.
- 4.3. For the purpose of this warranty, the following matters are excluded from the definition of Defect:
- (a) general wear and tear which is reasonably expected to occur over the life of the Product;
- (b) surface deterioration of panels caused by 'swarf' (tiny particles of steel debris left from cutting, grinding or drilling operations);
- (c) condensation caused by weather conditions such as extreme heat or cold;
- (d) defects in any fastening apparatus (screws, nuts, bolts, rivets, hasps or bolts);
- (e) leaks caused by driving rain;
- (f) improper installation, maintenance or handling of the Product;
- (g) movement, distortion, collapse or settling of the ground or the supporting structure on which the Product is installed; or
- (h) staining from foreign substances (including mould, mildew, dirt, grease, oil and any other substance).
- 4.4. To the extent permitted by law, ABSCO is not liable to compensate You for any:
- (a) increased costs or expenses;
- (b) loss of profit, revenue, business, contracts or anticipated savings;
- (c) loss or expense resulting from a claim by a third-party; or



(d) special, indirect or consequential loss or damage of any nature whatsoever, arising from a Defect in the Product or ABSCO's repair or replacement of the Product under this warranty.

#### 5. CONSUMER LAW

Australian Consumer Law

- 5.1. Clauses 5.2 to 5.3 apply where the Product was purchased in Australia.
- 5.2. The Product comes with guarantees that cannot be excluded under the Australian Consumer Law. You may be entitled to a replacement or refund for a major failure of the Product and compensation for any other reasonably foreseeable loss or damage. You may also be entitled to have the Product repaired or replaced if the Product fails to be of acceptable quality and the failure does not amount to a major failure.
- 5.3. The benefits of this Lifetime Warranty Statement are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this Lifetime Warranty Statement is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

New Zealand Consumer Law

- 5.4. Clauses 5.5 to 5.6 apply where the Product was purchased in New Zealand
- 5.5. This warranty is subject to the laws of New Zealand, including but not limited to the New Zealand Sale of Goods Act, the Consumer Guarantees Act and the Fair Trading Act.
- 5.6. The benefits of this Lifetime Warranty Statement are in addition to any rights and remedies imposed by New Zealand legislation that cannot be excluded. Nothing in this Lifetime Warranty Statement is to be interpreted as excluding, restricting or modifying any New Zealand legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

#### 6. NO REPRESENTATIONS / ENTIRE AGREEMENT

- 6.1. You agree and acknowledge that this Lifetime Warranty Statement contains the entire agreement between the Parties regarding the warranty provided by ABSCO to You in relation to the Product.
- 6.2. To the full extent permitted by law, this Lifetime Warranty Statement supersedes all other warranties of any kind, including whether express or implied by representations, statement, correspondence or other conditions such as merchantability or fitness for purpose.

#### 7. REGISTRATION OF WARRANTY

- 7.1. Please ensure that You keep this Lifetime Warranty Statement in a safe place along with your proof of purchase of the Product.
- 7.2. To ensure ABSCO has a record of your warranty, You can register Your warranty online at http://abscosheds.com.au/warranty-details/.

#### 4. WARRANTY LIMITATIONS / EXCLUSIONS

- 4.1. To the extent permitted by law, this warranty will not apply where:
- (a) the Product has been installed or used for a purpose that is not an Authorised Purpose;
- (b) the Product has not been installed, assembled, maintained and/or operated in complete compliance with ABSCO's Product Guide;
- (c) the Product has been used to store corrosive materials such as fertiliser or chlorine:
- (d) the Product was installed in excess of 12 months after the purchase of the Product;
- (e) the Product has not been installed in accordance with the relevant standards, codes and statutory regulations;
- (f) the Defect is determined to have been caused by storm, wind, rain, earthquake. fire, snow or poor foundations:
- (g) the Defect is, or is the result of, surface deterioration of panels caused by 'swarf' (tiny particles of steel debris left from cutting, grinding or drilling operations):
- (h) the Product has been installed in an Excluded Environment;
- (i) the Product has been subject to accident, negligence, alteration, abuse or misuse:
- (j) the Defect is determined to be the result of overloading; or
- (k) ABSCO determines that the Defect is the result of a failure of a thirdparty product.
- 4.2. You acknowledge that:
- (a) dimensions and colour of the Product are subject to normal manufacturing variations and tolerances, and that reasonable variances are not considered a Defect under this warranty; and
- (b) this warranty is limited to the repair or replacement of Defects in the Product and does not extend to any other product or any other consequential or indirect damage incurred as a result of the Defect.
- 4.3. For the purpose of this warranty, the following matters are excluded from the definition of Defect:
- (a) general wear and tear which is reasonably expected to occur over the life of the Product;
- (b) surface deterioration of panels caused by 'swarf' (tiny particles of steel debris left from cutting, grinding or drilling operations);
- (c) condensation caused by weather conditions such as extreme heat or cold;
- (d) defects in any fastening apparatus (screws, nuts, bolts, rivets, hasps or bolts);
- (e) leaks caused by driving rain;
- (f) improper installation, maintenance or handling of the Product;
- (g) movement, distortion, collapse or settling of the ground or the supporting structure on which the Product is installed; or
- (h) staining from foreign substances (including mould, mildew, dirt, grease, oil and any other substance).
- 4.4. To the extent permitted by law, ABSCO is not liable to compensate You for any:
- (a) increased costs or expenses;
- (b) loss of profit, revenue, business, contracts or anticipated savings;
- (c) loss or expense resulting from a claim by a third-party; or



(d) special, indirect or consequential loss or damage of any nature whatsoever, arising from a Defect in the Product or ABSCO's repair or replacement of the Product under this warranty.

#### 5. CONSUMER LAW

Australian Consumer Law

- 5.1. Clauses 5.2 to 5.3 apply where the Product was purchased in Australia.
- 5.2. The Product comes with guarantees that cannot be excluded under the Australian Consumer Law. You may be entitled to a replacement or refund for a major failure of the Product and compensation for any other reasonably foreseeable loss or damage. You may also be entitled to have the Product repaired or replaced if the Product fails to be of acceptable quality and the failure does not amount to a major failure.
- 5.3. The benefits of this Lifetime Warranty Statement are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this Lifetime Warranty Statement is to be interpreted as excluding, restricting or modifying any State or Federal legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

New Zealand Consumer Law

- 5.4. Clauses 5.5 to 5.6 apply where the Product was purchased in New Zealand
- 5.5. This warranty is subject to the laws of New Zealand, including but not limited to the New Zealand Sale of Goods Act, the Consumer Guarantees Act and the Fair Trading Act.
- 5.6. The benefits of this Lifetime Warranty Statement are in addition to any rights and remedies imposed by New Zealand legislation that cannot be excluded. Nothing in this Lifetime Warranty Statement is to be interpreted as excluding, restricting or modifying any New Zealand legislation applicable to the supply of goods and services which cannot be excluded, restricted or modified.

#### 6. NO REPRESENTATIONS / ENTIRE AGREEMENT

- 6.1. You agree and acknowledge that this Lifetime Warranty Statement contains the entire agreement between the Parties regarding the warranty provided by ABSCO to You in relation to the Product.
- 6.2. To the full extent permitted by law, this Lifetime Warranty Statement supersedes all other warranties of any kind, including whether express or implied by representations, statement, correspondence or other conditions such as merchantability or fitness for purpose.

#### 7. REGISTRATION OF WARRANTY

- 7.1. Please ensure that You keep this Lifetime Warranty Statement in a safe place along with your proof of purchase of the Product.
- 7.2. To ensure ABSCO has a record of your warranty, You can register Your warranty online at http://abscosheds.com.au/warranty-details/.