


ASSEMBLY APP AVAILABLE ON  + 

We highly recommend downloading the Absco Sheds Assembly App to assist with your build.



**STEP BY STEP ASSEMBLY VIDEOS • PARTS CHECKLISTS • FAQ • 7 DAY
CUSTOMER SERVICE • WARRANTY INFORMATION**



GENERAL INSTRUCTIONS

- Before commencing any assembly, read through these instructions in detail to gain a thorough understanding of assembly methods and associated details.
- Unpack the carton and carefully identify and check off all the parts against the parts described and illustrated on "COMPONENTS PACKING LIST" pages.

SITE PREPARATION

- The site for the shed must be level. An uneven surface may result in misalignment of parts.
- The shed shall be erected on top of a reinforced concrete slab and anchored down appropriately illustrated on "FINAL CONSTRUCTION" page.

SAFETY NOTES

- Some parts may have sharp edges. It is advisable to wear gloves when handling these items and safety glasses if drilling holes. Sensible shoes are highly recommended.
- Do not erect your shed in windy conditions.
- Ensure that the shed is securely anchored to a solid foundation immediately after construction is completed.
- It is highly recommended to erect the shed with two or more people.
- Do not sit, stand or walk on the roof of your shed.

RECOMMENDED



Personal protective equipment for tools



Hand Protection



Enclosed Shoes




Raised work surface. EG Sawhorses and timbers




Heavy and/or bulky. Multi-person lift or mechanical aid.

TOOLS REQUIRED



Tinsnips



Cordless drill




Pop riveter




Ladder

metal & masonry drill bits to suit anchor fasteners



Hammer drill



Shifter

NUMBER OF PEOPLE REQUIRED



1-2 people

NUMBER OF HOURS REQUIRED



Approx. 5 hours

ASSEMBLY DIFFICULTY

















Basic



Complex

COMPONENTS LIST




















Check off all components.

SHEETING							
QTY	COMPONENT DESCRIPTION	PART No.	CHK	QTY	COMPONENT DESCRIPTION	PART No.	CHK
1	 STEEL SHEET 70.3" x 30.4"	30A		1	 STEEL SHEET 70.3" x 30.4"	30E	
1	 STEEL SHEET 70.3" x 30.4"	30G		1	 STEEL SHEET 67.9" x 28"	37A	
2	 STEEL SHEET 62.7" x 30.4"	43A		4	 STEEL SHEET 23.6" x 30.4"	31D	
4	 MESH SHEET 47" x 27.8"	MESH20					
INSTRUCTIONS AND FITTINGS PACKET							
1	 DOOR PLATE	12A		1	 8G x 3/8" SELF TAPPING SCREW PACK QTY 220	FAST001	
6	 1/8" POP RIVET	FAST009		1	INSTRUCTION MANUAL	IM	
1	 PADBOLT 4.5" LONG	FAST006		1	 PADBOLT HASP	FAST007	
6	 3/16 x 1/2" CSK SCREW & NUT	FAST004 FAST005		1	 PHILLIPS HD DRIVER BIT	FAST038	
1	 1/8" DRILL BIT	DRILL		15	 8G x 3/4" SELF TAPPING SCREW	FAST013	

Nominal sheet widths are shown, +/- 0.08" is within tolerance


COMPONENTS LIST

Check off all components.



CHANNEL PACK							
QTY	COMPONENT DESCRIPTION	PART No.	CHK	QTY	COMPONENT DESCRIPTION	PART No.	CHK
3	 CHANNEL 70.3"	80L		1	 CHANNEL 59.6"	81F	
1	 CHANNEL 59.6"	53C		2	 CHANNEL 58.6"	53T	
2	 CHANNEL 59"	150		2	 CHANNEL 59"	151	
8	 CHANNEL 28"	181		2	 CHANNEL 59.6"	81E	
2	 CHANNEL 28"	58M		1	 CHANNEL 67.9"	58B	
1	 CHANNEL 68"	58A		1	 CHANNEL 28.3"	54G	
1	 JAMB 70.3"	89A		1	 JAMB 47.4"	70E	
1	 JAMB 70.3"	89B		2	 JAMB 42.5"	91E	
7	 JAMB 70.3"	70D		1	 JAMB 31.1"	91D	
2	 LIP TRIM 33.3"	88A					

ABSCO ASSEMBLY INTRODUCTION


The snaptite assembly system locks most perimeter channels to all roof and wall sheets without the need for tools and fasteners.




To pre-assemble the four wall panels and two roof panels, the perimeter channels are secured to the top and bottom of each panel using the snaptite system, as detailed on the following pages wherever you see the symbol.



After joining sheets together, position channel over one end of the sheets, gently tapping it over the snaptite lugs, working along the sheets to the other end.






Position sheets on timbers, trestles or partly over edge of concrete slab.



Each perimeter channel must finish flush with the edges of the sheets. The snaptite system allows adjustment for this process by simply tapping the channel along the sheets until each end is neatly flush. If you need to remove channels from the panels, pull the channel along the panel from opposing ends. You may need someone to help with this.


FASTENING SYMBOLS

-  **D** Join components together by pre-drilling the holes first. Use one component as a template to mark where the holes are. Drill with 3mm drill bit.
-  Join components together with one screw at this location only, as some channel sections have extra holes that are not required for this model of garden shed
-  Do not join components together at this location yet, as the screw may obstruct further assembly of other components

-  **POP RIVETS**
-  **NUT & BOLT SET**


ROOF AND WALL OVERVIEW

Door and mesh panels not shown for illustrative purposes.
Detailed steps on following pages.



REAR PANEL ASSEMBLY

1 required



1. Overlap specified sheets by a rib.

Make sure ends are flush and orientated as shown.


2. Fasten with self tapping screws through prepunched sheet-to-sheet holes on overlap.

If you can't see bottom hole twist the sheet left or right.

Make a new hole with supplied drill bit if bottom hole is too far up or down the sheet or not found.

3. Attach the top and bottom channels using the SNAP-TiTE method.


Make sure you have the short side of the channel to the outside of the sheeting



- This completes the rear panel -

ROOF PANEL ASSEMBLY

1x required





1. Overlap specified sheets as shown. Make sure ends are flush.

Where possible, keep sheets in the same orientation from the box.

2. Fasten with self tapping screws through prepunched sheet-to-sheet holes on overlap.


If you can't see bottom hole twist the sheet left or right.

Make a new hole with supplied drill bit if bottom hole is too far up or down the sheet or not found.



3. Attach the top and bottom channels using the SNAP-TITE method.

Make sure you have the short side of the channel to the outside of the sheeting



4. Place the 88A lips on both ends with the shorter side on top.

Align with holes in sheet and fasten with four self tapping screws each.

- This completes the roof panel -

DOOR PANEL ASSEMBLY

1x required

FAST001 x12

Narrow pan of sheet
to this side

SNAP
TITE

58M

Position 12A
midway along the
door.

58A

12A


37A

58B

58M

SNAP
TITE

Side channels of door
are to be orientated
opposite to top and
bottom channels.




0.8" flange

0.6" flange


FAST001 x4

FAST006

Side channels are
positioned behind top
and bottom channel.




Using the jambs as templates drill 1/8" holes into the sheet and secure with screws from the outside of the sheet.





- This completes the door panel -

LEFT SIDE PANEL

1x required




LEFT SIDE PANEL



NOTE: 31D sheet is positioned behind jamb 89B

- This completes the left side panel -

DOOR PANEL ASSEMBLY




Lay the LEFT SIDE PANEL face up and lay the DOOR PANEL down in the open position on top as shown.

Using three rivets per hinge, FAST009, secure the door to the frame.


NOTE: Run the 1/8" drill bit through the punched holes in the jamb before riveting the hinge on.

RIGHT SIDE PANEL

1x required




Part overview



RIGHT SIDE PANEL

2.


Prepare a short sheet




Notch out both bottom corners as shown using tin snips.

3.

FAST001 x2





4.




- This completes the right side panel -



FRONT PANEL



3.
Prepare two
short sheets




Notch out both bottom corners as shown using tinsnips.



- This completes the front panel -


FITTING MESH PANELS



The mesh panels are fixed to the **inside** of the wall panels.

There's six holes in the border of the mesh panel, these are fixed with FAST001 screws.

1. Start by aligning the middle pair of mesh holes with these lower 70D holes and fasten with screws from outside.



2. The four corner holes are to be drilled out into the top and bottom channels using the with the supplied 1/8" drill bit and fastened from inside the panel using four FAST001 screws.

3. Repeat these steps for every mesh position.


NOTE: If the mesh panel is not sitting flush enough for your liking you may drill more 1/8" holes and fasten with additional FAST001.

WARNING: It is recommended that new galvanised mesh should be weathered for two (2) months or scrubbed with a mild acidic solution, such as vinegar, then rinsed with water before being used in bird housing applications.


PANEL CONSTRUCTION

NOTE: Take care to ensure that all wall panels are not upside down. The top channels of each panel are pre-punched for attaching roof sheeting. The base channels are not pre-punched.

Mesh panels are not shown for illustrative purposes.





FINAL CONSTRUCTION



Line up the holes in the roof sheet with front and back top channels. Secure with screws.

Line up the holes in the roof lips with holes in the top channel of the side panels. Secure with screws.



Each anchor consists of one nut, bolt, dynabolt and steel angle.
Drill a hole into the wall sheet to suit the bolt
Drill a hole into the concrete to suit the dynabolt

EXPORT PRODUCT WARRANTY AGAINST DEFECTS

Congratulations on your purchase of an ABSCO SHED

ABSCO SHEDS, including garden sheds, garden beds, aviaries, storage units, garages, awnings and carports are made using high quality Australian made steel.

We are pleased to advise we warrant that the steel coating will not rust, crack, flake peel or blister for 12 years from date of purchase.

This warranty does not apply to surface deterioration of panels caused by 'Swarf' (Tiny particles of steel debris left from cutting, grinding or drilling operations) that has not been removed after building construction, or as a result of contact with damp soil, chemicals, fertilisers or other corrosive substances.

This warranty covers any Absco product used for normal domestic use and installed in accordance with the installation instructions.

This warranty does NOT cover Damage caused by storms, wind, rain, snow or poor foundations.

This warranty does NOT cover ABSCO products installed in severe coastal, industrial or other highly corrosive environments. The warranty does not cover fasteners (screws, nuts, bolts, rivets, hasps or sliding padbolts).

The warranty is limited to replacement and delivery of components and does not include any labour or installation costs. The benefits given by the warranty are in addition to your other rights and remedies under a law in relation to the goods or services to which the warranty relates.

In the unlikely event a warranty claim is made, it must be supported by photographic evidence and details of the defect, including component part numbers, together with proof of purchase documentation (or on-line registration of purchase) and forwarded to the address below. Upon receipt of the warranty claim, the Customer Service Manager will contact you within three business days to advise you of the assessment outcome of the claim, which may include your expenses incurred in making the claim.

THE CUSTOMER SERVICE MANAGER, ABSCO SHEDS, PO BOX 119 ACACIA RIDGE QLD AUSTRALIA 4110

PHONE: +1 (866) 788 3046

EMAIL: warranty@absco.com.au

Issued 16 July 2019